

Empfohlene Passung	Toleranzfeldlage und -größe für Nennmaß 60 in µm								
	Außenmaß					Innenmaß			
	400	300	200	100	0	100	200	300	400
H8/x8 ≤ 24 mm			x8		H8				
H8/u8 > 24 mm									
H7/s6									
H7/r6									
H7/n6									
H7/k6									
H7/j6									
H7/h6									
H8/h9									
H11/h9									
(H11/h11)									
G7/h6 *									
H7/g6									
H7/f7									
F8/h6 *									
H8/f7									
F8/h9 *									
H8/e8									
E9/h9 *									
H8/d9									
D10/h9 *									
(H11/d9)									
D10/h11 *									
C11/h9 *									
C11/h11 *									
(H11/c11)									
(A11/h11) *									
(H11/a11)									